





MODEL 133				
PUMP SIZE	D03	E03	F03	G03

NOTES


1. ALL DIMENSIONS IN INCHES.
2. NOT FOR CONSTRUCTION PURPOSES UNLESS CERTIFIED.
3. CONDUIT BOX IS SHOWN IN APPROXIMATE LOCATION. CAPACITOR WHEN FURNISHED NORMALLY APPEARS ON TOP OF MOTOR. DIMENSIONS ARE NOT SPECIFIED AS THEY VARY WITH EACH MOTOR MANUFACTURER.
4. DIMENSIONS MAY VARY ± 1/4".
5. CHECK DISCHARGE POSITION, CASING DIMENSIONS WHICH EXCEED DIMENSION "D" MAY REQUIRE PADS FOR THE MOTOR.
6. MOTOR FRAME 56.








POSITION (2)



POSITION (3)



POSITION (4)

	MODEL	134				135					
PUMP	SIZE	A04	B04	C04	D04	F05	G05	H05	I05	J05	K05

MODEL	SUCTION	DISCH.	DF	DG	X	YY
134	1	1	2	1-11/16	3-3/4	3-3/4
135	2	1-1/2	2-1/4	2-1/4	4-1/2	4-1/2

FRAME	A	B	D	E	F	F1	H	AG	BA
56	6-3/4	4	3-1/2	2-7/16	1-1/2	—	11/32 SLOT	11	2-9/16
143T	7	6	3-1/2	2-3/4	2	—	11/32 SLOT	10	2-7/8
145T	7	6	3-1/2	2-3/4	2-1/2	—	11/32 SLOT	11	2-7/8
182T	8-3/4	6-5/8	4-1/2	3-3/4	2-1/4	—	11/32 SLOT	11	3-5/8
184T	8-3/4	6-5/8	4-1/2	3-3/4	—	5-1/2	11/32 SLOT	12	3-5/8
213T	9-1/2	8	5-1/4	4-1/4	2-3/4	—	7/16	14	4-1/2
215T	9-1/2	8	5-1/4	4-1/4	3-1/2	—	7/16	15	4-1/2
254T	12-1/2	10-1/4	6-1/4	5	4-1/8	—	17/32	17	5

NOTES:
1. ALL DIMENSIONS IN INCHES.
2. NOT FOR CONSTRUCTION PURPOSES UNLESS CERTIFIED.
3. CONDUIT BOX IS SHOWN IN APPROXIMATE LOCATION. CAPACITOR WHEN FURNISHED NORMALLY APPEARS ON TOP OF MOTOR. DIMENSIONS ARE NOT SPECIFIED AS THEY VARY WITH EACH MOTOR MANUFACTURER.
4. DIMENSIONS MAY VARY ± 1/4".
5. CHECK DISCHARGE POSITION, CASING DIMENSIONS WHICH EXCEED DIMENSION "D" MAY REQUIRE PADS FOR THE MOTOR.